

XM series PARAMETERS	CODE	XM440K	XM460K	XM463K	XM470K
<b>REGULATION</b>					
Set point	Set	●	●	●	●
Differential	Hy	●	●	●	●
Minimum set point	LS	◆	◆	◆	◆
Maximum set point	US	◆	◆	◆	◆
Outputs activation delay at start up	OdS	◆	◆	◆	◆
Anti-short cycle delay	AC	●	●	●	●
Compressor on time with faulty probe	Con	◆	◆	◆	◆
Compressor off time with faulty probe	COF	◆	◆	◆	◆
<b>DISPLAY</b>					
Temperature measurement unit	CF	◆	◆	◆	◆
Resolution (integer/decimal point)	rES	●	●	●	●
Local display configuration	Lod	◆	◆	◆	◆
<b>DEFROST</b>					
Defrost type	tdF	●	●	●	●
Defrost mode	EdF	◆	◆	◆	◆
Set point for smart defrost	SdF	◆	◆	◆	◆
Defrost termination temperature	dtE	●	●	●	●
Interval between defrost cycles	ldF	●	●	●	●
(Maximum) length for defrost	MdF	●	●	●	●
Displaying during defrost	dFd	◆	◆	◆	◆
MAX display delay after defrost	dAd	◆	◆	◆	◆
Draining time	Fdt	◆	◆	◆	◆
First defrost after start up	dPO	◆	◆	◆	◆
Defrost probe selection	dFP	◆	◆	◆	◆
<b>FANS</b>					
Fans operating mode	Fnc		◆	◆	◆
Fans delay after defrost	Fnd		◆	◆	◆
Fans stop temperature	FSt		◆	◆	◆
Fans probe selection	FAP		◆	◆	◆
<b>ALARMS</b>					
Temperature alarms configuration	ALC	◆	◆	◆	◆
Maximum temperature alarm	ALU	●	●	●	●
Minimum temperature alarm	ALL	●	●	●	●
Temperature alarm differential	AFH	◆	◆	◆	◆
Temperature alarm delay	ALd	◆	◆	◆	◆
Delay of temperature alarm at start up	dAO	◆	◆	◆	◆
Alarm delay at the end of defrost	EdA	◆	◆	◆	◆
Alarm relay silencing	tbA				◆
Alarm probe selection	ALP	◆	◆	◆	◆
<b>ANALOG INPUTS</b>					
Thermostat probe calibration	Ot	●	●	●	●
Evaporator probe calibration	OE	◆	◆	◆	◆
Auxiliary probe calibration	O3	◆	◆	◆	◆
Evaporator probe presence	P2P	◆	◆	◆	◆
Auxiliary probe presence	P3P	◆	◆	◆	◆
Regulation probe selection	Pbr	◆	◆	◆	◆
Energy saving probe selection	ESP	◆	◆	◆	◆
Temperature increasing during energy saving cycle	HES	◆	◆	◆	◆
<b>DIGITAL INPUT</b>					
Energy saving digital input polarity	i1P	◆	◆	◆	◆
Configurable digital input polarity	i2P	◆	◆	◆	◆
Digital input configuration	i2F	◆	◆	◆	◆
Digital input alarm delay	dId	◆	◆	◆	◆
<b>LAN CONFIGURATION</b>					
LAN serial address	LAn	◆	◆	◆	◆
Master defrost synchronisation	LMd	◆	◆	◆	◆
Set point synchronisation	LSP	◆	◆	◆	◆
Display synchronisation	LdS	◆	◆	◆	◆
On/off synchronisation	LOF	◆	◆	◆	◆
Light synchronisation	LLi	◆	◆	◆	◆
Aux synchronisation	LAU	◆	◆	◆	◆
Energy saving synchronisation	LES	◆	◆	◆	◆
Remote probe display	LSd	◆	◆	◆	◆
<b>OTHER</b>					
RS485 Serial address	Adr	●	●	●	●
P1's value displaying (reading only)	dP1	◆	◆	◆	◆
P2's value displaying (reading only)	dP2	◆	◆	◆	◆
P3's value displaying (reading only)	dP3	◆	◆	◆	◆
Software release (reading only)	rEL	◆	◆	◆	◆
Map code (reading only)	Ptb	◆	◆	◆	◆
Working days defrost start	Ld1-Ld8	◆	◆	◆	◆
Holiday defrost start	Sd1-Sd8	◆	◆	◆	◆
Clock board presence	CbP	◆	◆	◆	◆
Current hour	Hur	◆	◆	◆	◆
Current minutes	Min	◆	◆	◆	◆
Current day of the week	dAy	◆	◆	◆	◆
Holiday selection	hd1-hd3	◆	◆	◆	◆
Energy saving start during working days	ILE	◆	◆	◆	◆
Energy saving length during working days	dLE	◆	◆	◆	◆
Energy saving start during holiday	ISE	◆	◆	◆	◆
Energy saving length during holiday	dSE	◆	◆	◆	◆
Temperature increase during energy saving	HES	◆	◆	◆	◆

● present      ◆ present and factory pre-set