

PRIME series PARAMETERS	CODE	XR10C	XR20C	XR30C	XR40C	XR60C	XR70C	XR72C	XR80C	XR10D	XR20D	XR30D	XR40D	XR60D	XR70D	XR80D
<b>REGULATION</b>																
Set point	Set	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Differential	Hy	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Minimum set point	LS	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Maximum set point	US	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Thermostat probe calibration	Ot	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Evaporator probe presence	P2P				●	●	●	●					●	●	●	
Evaporator probe calibration	OE				◆	◆	◆	◆					◆	◆	◆	
Outputs activation delay at start up	OdS	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Anti-short cycle delay	AC	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
2 <sup>nd</sup> compressor delay	AC1							●								
Compressor ON time during fast freezing	CCt		◆	◆	◆	◆	◆	◆			◆	◆	◆	◆	◆	
Compressor ON time with faulty probe	Con	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Compressor OFF time with faulty probe	COF	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Kind of action (cooling /heating)	CH	●	●	●						●	●	●				
<b>DISPLAY</b>																
Temperature measurement unit	CF	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Resolution (integer/decimal point)	rES	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Local display configuration	Lod				◆	◆	◆	◆					◆	◆	◆	
Evaporator probe display	Prd												◆	◆	◆	
1 probe display	dP1				◆	◆	◆	◆								
2 probe display	dP2				◆	◆	◆	◆								
<b>DEFROST</b>																
Defrost type	tdF				●	●	●	●					●	●	●	
Defrost termination temperature	dtE				●	●	●	●					●	●	●	
Interval between defrost cycles	ldF		●	●	●	●	●	●			●	●	●	●	●	
(Maximum) length for defrost	MdF		●	●	●	●	●	●			●	●	●	●	●	
Defrost start delay	dSd				◆	◆	◆	◆					◆	◆	◆	
Displaying during defrost	dFd		◆	◆	◆	◆	◆	◆			◆	◆	◆	◆	◆	
Max display delay after defrost	dAd		◆	◆	◆	◆	◆	◆			◆	◆	◆	◆	◆	
Draining time	Fdt				◆	◆	◆	◆			◆	◆	◆	◆	◆	
First defrost after startup	dPO				◆	◆	◆	◆					◆	◆	◆	
Defrost delay after fast freezing	dAF				◆	◆	◆	◆					◆	◆	◆	
<b>FANS</b>																
Fans operating mode	Fnc					●	●	●							●	●
Fans delay after defrost	Fnd					●	●	●						●	●	
T. differential against short cycles of fan	Fct				◆	◆	◆	◆								
Fans stop temperature	FSt					●	●	●						●	●	
<b>AGITATION CYCLE</b>																
Agitator configuration	AGc								◆							◆
Resolution for iAg parameter (min/sec)	iIC								◆							◆
Interval between agitation cycles	iAG								●							●
Length for agitation cycle	AGt								●							●
Agitation at power on	APO								◆							◆
<b>ALARM</b>																
Temperature alarms configuration	ALC	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Maximum temperature alarm	ALU	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Minimum temperature alarm	ALL	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Temperature alarm delay	ALd	◆	◆	◆	◆	◆	◆	◆	●	◆	◆	◆	◆	◆	◆	●
Delay of temperature alarm at start up	dAO	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
AUX output configuration	OA1			◆												
Alarm output polarity	AOP			◆			◆									
<b>2° RELAY AND DIGITAL INPUT</b>																
Alarm relay silencing	tbA			◆			◆					◆			◆	
2nd relay configuration	OAC											●				
Digital input polarity	i1P	●	●	●	●	●	●	●		●	●	●		●	●	
Digital input configuration	i1F	●	●	●	●	●	●	●		●	●	●		●	●	
Digital input alarm delay	dId	●	●	●	●	●	●	●		●	●	●		●	●	
Pressure switch activation number	nPS	◆	◆	◆	◆	◆	◆	◆						◆	◆	
Open door control	odC	◆	◆	◆	◆	◆	◆	◆						◆	◆	
<b>OTHER</b>																
Probe selection	Pbc	●	●	●	●	●	●	●	●	●	●	●	●			●
Software release	rEL	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
Map code	Ptb	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆

● present      ◆ present and factory pre-set