

WING series PARAMETERS	CODE	XW220	XW230	XW260 XW263	XW264	XW270	XW271	XW272	XW563 XW570
REGULATION									
Set point	Set	●	●	●	●	●	●	●	●
Differential	Hy	●	●	●	●	●	●	●	●
Minimum set point	LS	◆	◆	◆	◆	◆	◆	◆	◆
Maximum set point	US	◆	◆	◆	◆	◆	◆	◆	◆
Outputs activation delay at start up	OdS	◆	◆	◆	◆	◆	◆	◆	◆
Compressor configuration	CCO							◆	◆
Anti-short cycle delay	AC	●	●	●	●	●	●	●	●
Time delay between turning on compressors 1 and 2	AC1							◆	
Compressor on time during fast freezing	CCt	◆	◆	◆	◆	◆	◆	◆	◆
Compressor on time with faulty probe	Con	◆	◆	◆	◆	◆	◆	◆	◆
Compressor off time with faulty probe	COF	◆	◆	◆	◆	◆	◆	◆	◆
Heating - cooling	CH	◆							
DISPLAY									
Temperature measurement unit	CF	◆	◆	◆	◆	◆	◆	◆	◆
Resolution (integer/decimal point)	rES	●	●	●	●	●	●	●	●
Local display configuration	Lod	◆	◆	◆	◆	◆	◆	◆	◆
Remote display	rDd	◆	◆	◆	◆	◆	◆	◆	◆
DEFROST									
Defrost type	tdF			●	●	●	●	●	●
Defrost mode	EdF	◆	◆	◆	◆	◆	◆	◆	◆
Set point for smart defrost	SdF			◆	◆	◆	◆	◆	◆
Defrost termination temperature (1 st evap.)	dtE			●	●	●	●	●	●
Defrost termination temperature (2 nd evap.)	dtS				●				
Interval between defrost cycles	ldF	●	●	●	●	●	●	●	●
(Maximum) length for defrost (1 st evap.)	MdF	●	●	●	●	●	●	●	●
(Maximum) length for defrost (2 nd evap.)	MdS				●				
Displaying during defrost	dFd	◆	◆	◆	◆	◆	◆	◆	◆
Max display delay after defrost	dAd	◆	◆	◆	◆	◆	◆	◆	◆
Draining time	Fdt			◆	◆	◆	◆	◆	◆
First defrost after startup	dPO	◆	◆	◆	◆	◆	◆	◆	◆
Defrost delay after fast freezing	dAF	◆	◆	◆	◆	◆	◆	◆	◆
FANS									
Fans operating mode	Fnc			◆	◆	◆	◆	◆	◆
Fans delay after defrost	Fnd			◆	◆	◆	◆	◆	◆
Fans stop temperature	FSt			◆	◆	◆	◆	◆	◆
ALARMS									
Temperature alarms configuration	ALC	◆	◆	◆	◆	◆	◆	◆	◆
Maximum temperature alarm	ALU	●	●	●	●	●	●	●	●
Minimum temperature alarm	ALL	●	●	●	●	●	●	●	●
Temperature alarm differential	AFH	◆	◆	◆	◆	◆	◆	◆	◆
Temperature alarm delay	ALd	◆	◆	◆	◆	◆	◆	◆	◆
Delay of temperature alarm at start up	dAO	◆	◆	◆	◆	◆	◆	◆	◆
Alarm delay at the end of defrost	EdA	◆	◆	◆	◆	◆	◆	◆	◆
Delay of temperature alarm after closing the door	dOt	◆	◆	◆	◆	◆	◆	◆	◆
Open door alarm delay	dOA	◆	◆	◆	◆	◆	◆	◆	◆
Alarm relay silencing	tbA		◆						◆
Pressure switch activation number	nPS	◆	◆	◆	◆	◆	◆	◆	◆
ANALOG OUTPUT (OPTIONAL)									
Analog output start point	AOS	◆	◆	◆	◆	◆	◆	◆	◆
Analog output band width	APb	◆	◆	◆	◆	◆	◆	◆	◆
Input type for the analog output	CAO	◆	◆	◆	◆	◆	◆	◆	◆
ANALOG INPUTS									
Thermostat probe calibration	Ot	●	●	●	●	●	●	●	●
Evaporator probe calibration	OE			◆	◆	◆	◆	◆	◆
Auxiliary probe calibration	O3	◆	◆	◆	◆	◆	◆	◆	◆
Evaporator probe presence	P2P			◆	◆	◆	◆	◆	◆
Auxiliary probe presence	P3P	◆	◆	◆	◆	◆	◆	◆	◆
Temperature increasing during energy saving cycle	HES	◆	◆	◆	◆	◆	◆	◆	◆
DIGITAL INPUT									
Open door control	OdC	◆	◆	◆	◆	◆	◆	◆	◆
Door switch polarity	i1P	◆	◆	◆	◆	◆	◆	◆	◆
Configurable digital input polarity	i2P	◆	◆	◆	◆	◆	◆	◆	◆
Digital input configuration	i2F	◆	◆	◆	◆	◆	◆	◆	◆
Digital input alarm delay	dId	◆	◆	◆	◆	◆	◆	◆	◆
Set Point for anti-condensing heater	SAA						◆		
OTHER									
Serial address	Adr	●	●	●	●	●	●	●	●
Software release	rEL	◆	◆	◆	◆	◆	◆	◆	◆
Map code	Ptb	◆	◆	◆	◆	◆	◆	◆	◆
REAL TIME CLOCK									
Working days defrost start	Ld1-Ld8								◆
Holiday defrost start	Sd1-Sd8								◆
Energy saving start during working days	ILE								◆
Energy saving length during working days	dLE								◆
Energy saving start during holiday	ISE								◆
Energy saving length during holiday	dSE								◆
Temperature increase during Energy saving	HES								◆
Holiday selection	hd1-hd3								◆

● present ◆ present and factory pre-set