

WING BASIC series PARAMETERS	CODE	XW10L XW10V	XW20L XW20V XW20VS	XW20LS	XW30L XW30V XW30VS	XW35VS	XW40L XW40V XW40VS	XW60L XW60V XW60VS	XW60LS
<b>REGULATION</b>									
Set point	Set	●	●	●	●	●	●	●	●
Differential	Hy	●	●	●	●	●	●	●	●
Minimum set point	LS	◆	◆	◆	◆	◆	◆	◆	◆
Maximum set point	US	◆	◆	◆	◆	◆	◆	◆	◆
Outputs activation delay at start up	OdS	◆	◆	◆	◆	◆	◆	◆	◆
Anti-short cycle delay	AC	●	●	●	●	●	●	●	●
Compressor on time during fast freezing	CCt	◆	◆	◆	◆	◆	◆	◆	◆
Compressor on time with faulty probe	Con	◆	◆	◆	◆	◆	◆	◆	◆
Compressor off time with faulty probe	COF	◆	◆	◆	◆	◆	◆	◆	◆
Heating - cooling	CH	◆	◆	◆	◆	◆			
<b>DISPLAY</b>									
Temperature measurement unit	CF	◆	◆	◆	◆	◆	◆	◆	◆
Resolution (integer/decimal point)	rES	●	●	●	●	●	●	●	●
Local display configuration	Lod						◆	◆	◆
<b>DEFROST</b>									
Defrost type	tdF						●	●	◆
Defrost mode	EdF			◆	◆	◆	◆	◆	◆
Set point for smart defrost	SdF						◆	◆	◆
Defrost termination temperature	dtE						●	●	●
Interval between defrost cycles	IdF		●	●	●	●	●	●	●
(Maximum) length for defrost	MdF		●	●	●	●	●	●	●
Displaying during defrost	dFd		◆	◆	◆	◆	◆	◆	◆
Max display delay after defrost	dAd		◆	◆	◆	◆	◆	◆	◆
Delay before defrost	dSd								◆
Draining time	Fdt						◆	◆	◆
First defrost after startup	dPO			◆	◆	◆	◆	◆	◆
Defrost delay after fast freezing	dAF		◆	◆	◆	◆	◆	◆	◆
<b>FANS</b>									
Fans operating mode	Fnc					◆		●	◆
Fans delay after defrost	Fnd					◆		●	◆
Fans stop temperature	FSt							●	◆
<b>ALARMS</b>									
Temperature alarms configuration	ALC	◆	◆	◆	◆	◆	◆	◆	◆
Maximum temperature alarm	ALU	●	●	●	●	●	●	●	●
Minimum temperature alarm	ALL	●	●	●	●	●	●	●	●
Temperature alarm differential	AFH	◆	◆	◆	◆	◆	◆	◆	◆
Temperature alarm delay	Ald	●	●	◆	◆	◆	●	●	◆
Delay of temperature alarm at start up	dAO	◆	◆	◆	◆	◆	◆	◆	◆
Alarm delay at the end of defrost	EdA		◆	◆	◆	◆	◆	◆	◆
Delay of temperature alarm after closing the door	dOt	◆	◆		◆	◆	◆	◆	
Open door alarm delay	dOA	◆	◆		◆	◆	◆	◆	
Alarm relay silencing	tbA				◆				
Pressure switch activation number	nPS	◆	◆		◆	◆	◆	◆	
<b>ANALOG INPUTS</b>									
Thermostat probe calibration	Ot	●	●	●	●	◆	●	●	●
Evaporator probe calibration	OE						◆	◆	◆
Display probe calibration	O3					◆			
Evaporator probe presence	P2P						◆	◆	◆
Display probe presence	P3P					◆			
Temperature increasing during energy saving cycle	HES	◆	◆		◆	◆	◆	◆	
<b>DIGITAL INPUT</b>									
Open door control	Odc				◆	◆			
Configurable digital input polarity	i2P	◆	◆		◆	◆	◆	◆	
Digital input configuration	i2F	◆	◆		◆	◆	◆	◆	
Digital input alarm delay	dId	◆	◆		◆	◆	◆	◆	
<b>OTHER</b>									
Serial address	Adr					◆			
Alarm relay polarity	oP2				◆				
Third relay configuration	oA1								◆
Kind of probe	Pbc			◆	◆	◆			◆
Software release	rEL	◆	◆	◆	◆	◆	◆	◆	◆
Map code	Ptb	◆	◆	◆	◆	◆	◆	◆	◆
Probes display	Prd			◆	◆	◆			◆
Access parameter list	Pr2			●	●	●			●

● present

◆ present and factory pre-set